



**ADLINK**  
TECHNOLOGY INC.

# TALOS-3012

EtherCAT Master Controller  
**User's Manual**



**Manual Rev.:** 2.00  
**Revision Date:** Sept. 10, 2015  
**Part No:** 50-1Z186-1000

**Advance Technologies; Automate the World.**

# Revision History

Revision	Release Date	Description of Change(s)
2.00	Sept. 10, 2015	Initial Release

# Preface

## **Copyright 2015 ADLINK Technology, Inc.**

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

## **Disclaimer**

The information in this document is subject to change without prior notice in order to improve reliability, design, and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

## **Environmental Responsibility**

ADLINK is committed to fulfill its social responsibility to global environmental preservation through compliance with the European Union's Restriction of Hazardous Substances (RoHS) directive and Waste Electrical and Electronic Equipment (WEEE) directive. Environmental protection is a top priority for ADLINK. We have enforced measures to ensure that our products, manufacturing processes, components, and raw materials have as little impact on the environment as possible. When products are at their end of life, our customers are encouraged to dispose of them in accordance with the product disposal and/or recovery programs prescribed by their nation or company.

## **Trademarks**

Product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

## Conventions

Take note of the following conventions used throughout this manual to make sure that users perform certain tasks and instructions properly.



NOTE:

Additional information, aids, and tips that help users perform tasks.

---



Information to prevent **minor** physical injury, component damage, data loss, and/or program corruption when trying to complete a task.

---



Information to prevent **serious** physical injury, component damage, data loss, and/or program corruption when trying to complete a specific task.

---

# Table of Contents

<b>Preface</b> .....	<b>iii</b>
<b>List of Tables</b> .....	<b>ix</b>
<b>List of Figures</b> .....	<b>xi</b>
<b>1 Introduction</b> .....	<b>1</b>
1.1 Overview .....	1
1.2 Features .....	2
1.3 Specifications .....	3
1.4 Unpacking Checklist .....	5
1.5 Mechanical Drawings .....	6
1.6 Front Panel I/O Connectors .....	8
1.6.1 Power Button .....	8
1.6.2 LED Indicators .....	9
1.6.3 Reset Button .....	9
1.6.4 HDMI Connector .....	9
1.6.5 EtherCAT Port .....	10
1.6.6 Gigabit Ethernet Port .....	11
1.6.7 USB 3.0 Port .....	11
1.7 (Right) Side Panel I/O Connectors .....	11
<b>2 Getting Started</b> .....	<b>13</b>
2.1 Connecting DC power .....	13
2.2 DIN Rail Mounting .....	14
2.3 Cooling Considerations .....	15
<b>3 Project Creation</b> .....	<b>17</b>
3.1 Creating a Project .....	17
3.2 Starting a Task in CoDeSys IDE Environment .....	21
Start a Task .....	21

Build, Log In, and Start the Project .....	22
3.3 Troubleshooting .....	24
3.4 Errors .....	28
3.5 RTE Setting.....	30
<b>A Appendix: PLC Handler .....</b>	<b>35</b>
A.1 In CoDeSys.....	35
A.1.1 Configuring Symbols.....	35
A.2 In Windows .....	37
A.2.1 Mapping Variables .....	37
<b>B Appendix: BIOS Setup.....</b>	<b>39</b>
B.1 Main .....	40
B.1.1 BIOS Information .....	40
B.1.2 System Time/System Date .....	40
B.1.3 System Management.....	41
Board Information .....	41
Temperatures and Fan Speed .....	41
Power Consumption .....	41
Runtime Statistics .....	42
Flags .....	42
Power Up .....	42
B.2 Advanced.....	43
B.2.1 CPU Configuration.....	44
Limit CPUID Maximum .....	44
Execute Disable Bit .....	44
Intel Virtualization Technology .....	44
Power Technology .....	44
B.2.2 SATA Configuration.....	48
Serial-ATA (SATA) .....	48
SATA Speed Support .....	48
SATA Mode .....	48

Serial-ATA Port 0 .....	48
SATA Port0 HotPlug .....	49
B.2.3 USB Configuration.....	49
Legacy USB Support .....	49
XHCI Hand-Off .....	49
EHCI Hand-Off .....	50
USB Mass Storage Driver Support .....	50
USB transfer time-out .....	50
Device reset time-out .....	50
Device power-up delay .....	50
B.2.4 SDIO Configuration .....	52
SDIO Access Mode .....	52
B.2.5 Network Configuration.....	53
Network Stack .....	53
B.2.6 Baytrail Feature Configuration.....	54
LPSS & SCC Devices Mode .....	54
SCC SD Card Support .....	54
DDR50 Support for SD Card .....	54
MIPI HSI Support .....	54
LPSS HSUART # Support .....	54
HSUART Port Mode .....	55
B.2.7 ACPI Setting.....	55
Enable ACPI Auto Configuration .....	55
Enable Hibernation .....	55
ACPI Sleep State .....	55
Lock Legacy Resources .....	56
B.2.8 Thermal Configuration.....	56
Critical Trip Point .....	56
Passive Trip Point .....	56
Active Cooling Trip Point .....	56
B.2.9 Security Configuration .....	57
TXE .....	57

TXE HMRFB0 .....	57
TXE Firmware Update .....	57
TXE EOP Message .....	57
TXE Unconfiguration Perform .....	57
B.2.10 Miscellaneous Configuration.....	58
OS Selection .....	58
B.3 Security .....	59
Administrator Password .....	59
User Password .....	59
B.4 Boot .....	60
Setup Prompt Timeout .....	60
Bootup Num-Lock State .....	60
Quiet Boot .....	60
Fast Boot .....	60
Boot Option Priorities .....	61
B.5 Exit.....	63
Save Changes and Exit .....	63
Discard Changes and Exit .....	63
Save Changes and Reset .....	63
Discard Changes and Reset .....	63
Save Changes .....	63
Discard Changes .....	64
Restore Defaults .....	64
Save as User Defaults .....	64
Restore User Defaults .....	64
Launch EFI Shell from filesystem device .....	64
Reset System with ME disable ModeMEUD000 .....	64
<b>Important Safety Instructions.....</b>	<b>65</b>
<b>Getting Service .....</b>	<b>67</b>



## List of Tables

Table 1-1:	TALOS-3012 Front Panel I/O Connector Legend.....	8
Table 1-2:	LED Indicators .....	9
Table 1-3:	HDMI Pin Assignment .....	10
Table 1-4:	EtherCAT Port LED Function .....	11
Table 1-5:	Gigabit Ethernet Port LED Function .....	11
Table 1-6:	TALOS-3012 Rear Panel I/O Connector Legend .....	12

This page intentionally left blank.

## List of Figures

Figure 1-1:	TALOS-3012 Functional Block Diagram.....	5
Figure 1-2:	Top View.....	6
Figure 1-3:	Front View .....	7
Figure 1-4:	(Right) Side View.....	7
Figure 1-5:	Front Panel I/O .....	8
Figure 1-6:	(Right) Side Panel I/O.....	12

This page intentionally left blank.

# 1 Introduction

## 1.1 Overview

ADLINK's EtherCAT solutions comprise a complete package, from hardware to middleware to software, with every element tailored for dedicated EtherCAT functionality. Talos master controllers, EPS slave systems, and remote monitoring and control mechanisms combine with ADLINK's Softmotion one-stop control kernel to deliver flexible and easy-to-use intelligent platforms for next-generation Smart Factory environments.

At a compact 100 x 120 x 55 mm (L x W x H), ADLINK's newest Talos-3012 is a palm-size EtherCAT master controller powered by x86 processors. Based on the Intel Atom quad-core processor E3845 1.9GHz, with IEC 61131-3 compliant syntaxes, the Talos master controller allows easy emigration of legacy PLC programming to a PC-based environment, with a single master controller able to connect up to 64 axes and up to 10,000 I/O points of control through a daisy-chained slave system.

In addition, the Talos delivers plug-and-play functionality with numerous leading servo motor systems with more coming online every day.

ADLINK's Talos series provides a complete IEC 61131-3 edition environment supporting 5 common PLC syntaxes, powered by the ADLINK Softmotion kernel, with application-oriented function blocks simplifying use and shortening development time. ADLINK's Softmotion kernel is based on an efficient algorithm to increase precision, speed, and synchronous motion control capability, reducing operational complexity and development period for a wide variety of industrial applications.

An optimized middleware PLC Handler library allows development of owned Human-Machine-Interface (HMI), and the remaining GbE LAN enables terminal function for data exchange to intranet and internet networks. Rugged construction assures operation in harsh environments, with operating shock tolerance up to 100G, an extended operating temperature range of -20°C to 60°C, and optimal EMI resistance with a EN 61000 EMC certification.

## 1.2 Features

- ▶ Intel® Atom™ SoC processor E3845
- ▶ ADLINK Softmotion
- ▶ Supports IEC 61131-3-compliant programming environment
- ▶ Minimal control cycle time within 250  $\mu$ s
- ▶ Motion control of up to 64 axes and up to 10,000 I/O points of control
- ▶ Supports EtherCAT COE, FOE as well as EOE protocols
- ▶ Code executable when host Windows system crashes
- ▶ 3 user-defined indicators for CTR diagnostic
- ▶ Built-in SD socket for logging manufacturing data
- ▶ Rugged, compact construction with fanless design at -20°C to 60°C



NOTE:

Minimal control cycle is based on light workloads on both PLC and EtherCAT transmissions of less than 1,000 I/O.

---

## 1.3 Specifications

Specifications		
System Core		
Processor	Intel® Atom™ E3845	
Chipset	SoC with processor	
Video	1x HDMI	
Memory	RAM (Program & Data Memory)	2 GB DDR3L 1066 MHz memory down
	Retain Memory	Configurable on SD card
	Storage (Data Usage)	16 GB SSD / SD card
Connectivity		
EtherCAT	1 (1x Intel® I210IT)	
Ethernet	1 GbE (1x Intel® I210IT)	
Serial	1x RS-232 (COM1) 1x BIOS-programmable RS-232/422/485 (COM2)	
USB	1 USB 3.0, 2 USB 2.0	
Miscellaneous		
Programming Environment	CoDeSys V3.5 (IEC 61131-3 Compliant)	
	ADLINK Softmotion Function Blocks (details in ADLINK Talos Series FLR document)	
Power Supply		
DC Input	Built-in 6-36 VDC wide-range DC input 3P pluggable connectors with latch (GND, V-, V+)	
AC Input	Optional 40W external AC/DC adapter for AC input	
Mechanical		
Dimensions	120 (W) x 100 (D) x 55 (H) mm (4.68" x 3.9" x 2.17")	
Weight	650g (1.43 lb.)	
Mounting	DIN-Rail / Wall-mount kit	
Environmental		

Specifications	
Operating Temperature	Standard: 0°C to 50°C (w/HDD) Extended Temperature: -20°C to 60°C (w/ industrial mSATA)
Storage Temperature	-40°C to 85°C (excl. HDD/SDD/CFAST)
Humidity	Approx. 95% @ 40°C (non-condensing)
Vibration	Operating, 5 Grms, 5-500 Hz, 3 axes (w/ mSATA)
ESD	Contact +/-4 KV and Air +/-8 KV
Shock	Operating, 50 G half sine 11 ms duration (w/ mSATA)
EMC	CE and FCC Class A
Safety	UL, CB



Cold boot of the system at -20°C and operation with 100% loading at 60°C is provided when the industrial solid-state drive storage option is implemented.

Power Consumption		
Power off	0.3W	In shutdown mode with DC input and only USB keyboard/mouse
System Idle	6.3W	Under Windows Desktop with no application programs executed
Processor full load	12.5W	Under Windows with 100% CPU utilization and 2D/3D graphics load
System full load	22W	Under Windows with 100% CPU utilization and simultaneous access to all I/O devices
Recommended power supply	40W	With consideration of voltage de-rating under high environmental temperature






Figure 1-1: TALOS-3012 Functional Block Diagram

## 1.4 Unpacking Checklist

Before unpacking, check the shipping carton for any damage. If the shipping carton and/or contents are damaged, inform your dealer immediately. Retain the shipping carton and packing materials for inspection. Obtain authorization from your dealer before returning any product to ADLINK. Ensure that the following items are included in the package.

- ▶ Talos-3012 controller
- ▶ DIN-Rail / Wall-mount bracket
- ▶ Screw pack for DIN-Rail / Wall-mounting
- ▶ Quick Start Guide



CAUTION:

The Talos-3012 does not support user-initiated OS reinstall or repair. Talos-3012 performance cannot be guaranteed in the event of configuration changes deviating from the original software installation.

## 1.5 Mechanical Drawings



NOTE:

All dimensions shown are in millimeters (mm) unless otherwise stated.




Figure 1-2: Top View




Figure 1-3: Front View





Figure 1-4: (Right) Side View

## 1.6 Front Panel I/O Connectors

This section describes the I/O connectors located on the front panel of the TALOS-3012.



**Figure 1-5: Front Panel I/O**

<b>A</b>	Power button	<b>F</b>	USB 2.0 port x2
<b>B</b>	Reset button	<b>G</b>	USB 3.0 (Push-Push, Type II)
<b>C</b>	LED status indicators	<b>H</b>	GbE port
<b>D</b>	HDMI	<b>J</b>	EtherCAT port
<b>E</b>	User-defined LED indicators	<b>K</b>	ISD card

**Table 1-1: TALOS-3012 Front Panel I/O Connector Legend**

### 1.6.1 Power Button

The power button is a non-latched push button with a blue LED indicator. System is turned on when button is pressed, and the power LED lit. If the system hangs, depressing the button for 5 seconds powers down the system.

## 1.6.2 LED Indicators

In addition to the LED of the power button, three LEDs on the front panel indicate the following operations.

Indicator	Color	Description
Watchdog (WDT)	Yellow	Indicates watchdog timer status. Flashes when watchdog timer starts, and when timer is expired, system will auto-reboots.
Hard disk drive	Orange	When blinking, indicates the SATA hard driver is active
Standby	Blue	Indicates the system is in power standby mode


**Table 1-2: LED Indicators**

## 1.6.3 Reset Button

The reset button executes hard reset for the TALOS-3012.

## 1.6.4 HDMI Connector

Provides connection to HDMI monitor or VGA, DVI monitor via HDMI-to-VGA adapter cable, and HDMI-to-DVI adapter cable.




PIN	Signal	PIN	Signal
1	TMDS_DATA2+	11	TMDS_CLOCK_SHIELD
2	TMDS_DATA2_SHIELD	12	TMDS_CLOCK-
3	TMDS_DATA2-	13	CEC
4	TMDS_DATA1+	14	RESERVED
5	TMDS_DATA1_SHIELD	15	SCL
6	TMDS_DATA1-	16	SDA
7	TMDS_DATA0+	17	DDC/CEC GROUND
8	TMDS_DATA0_SHIELD	18	+5V POWER
9	TMDS_DATA0-	19	HOT PLUG DETECT
10	TMDS_CLOCK+		

**Table 1-3: HDMI Pin Assignment**

### 1.6.5 EtherCAT Port

The dedicated EtherCAT port provides connection to EtherCAT slave devices, implementing the Intel WGI210IT GbE controller, qualified by numerous EtherCAT software master stacks and including the CoDeSys platform.



LED	LED Color	Status	Description
Active/Link	Yellow	OFF	Port is disconnected
		ON	Port is connected with no activity
		Flashing	Port is connected and active

LED	LED Color	Status	Description
Speed	Green/ Orange	OFF	10 Mbps
		Green	100 Mbps
		Orange	1000 Mbps

**Table 1-4: EtherCAT Port LED Function**

### 1.6.6 Gigabit Ethernet Port

The Gigabit Ethernet port is based on an Intel WGI210IT GbE controller.

LED	LED Color	Status	Description
Active/Link	Yellow	OFF	Port is disconnected
		ON	Port is connected with no activity
		Flashing	Port is connected and active
Speed	Green/ Orange	OFF	10 Mbps
		Green	100 Mbps
		Orange	1000 Mbps

**Table 1-5: Gigabit Ethernet Port LED Function**

### 1.6.7 USB 3.0 Port

The USB 3.0 port supports Type A connection, compatible with SuperSpeed, Hi-Speed, full-speed and low-speed USB devices, with support for multiple boot devices, including USB flash, USB external HDD, and USB CD-ROM drivers and boot priority and boot device configured in BIOS.




NOTE:

When using USB CD-ROM via USB 3.0 port to re-install or repair the OS, cold boot should be utilized

## 1.7 (Right) Side Panel I/O Connectors

This section describes I/O connectors located on the side panel of the TALOS-3012.



**Figure 1-6: (Right) Side Panel I/O**

<b>A</b>	DC power supply connector
<b>B</b>	DB-9P COM Ports

**Table 1-6: TALOS-3012 Rear Panel I/O Connector Legend**



## 2 Getting Started

### 2.1 Connecting DC power

---



Before providing DC power to the TALOS-3012, ensure the voltage and polarity provided are compatible with the DC input. Improper input voltage and/or polarity can be responsible for system damage.

---

The DC power input connector of the TALOS-3012 utilizes V+, V-, and chassis ground pins, and accepts input voltage as shown previously.

1. Connect DC power cables as shown.
2. Fix the DC connector using the 2 screws.




## 2.2 DIN Rail Mounting

The TALOS-3012 controller is shipped with DIN rail mounting brackets and accessory screws, with mounting procedures as follows.

1. Prepare the DIN rail mount brackets and 2 M4-F head screws included in the package.



2. Use the 2 included M4-F head screws to fix the DIN rail mount brackets to the chassis, according to the spacing dimensions of the screw holes and brackets, as shown.



## 2.3 Cooling Considerations


Heat-generating components of the TALOS-3012 (such as CPU and PCH) are all situated on the left side of the system. These components directly contact the heat sink via thermal pads and dissipate heat generated by the components. To maximize efficiency of heat dissipation, maintain a minimum of 2 inches (5 cm) clearance on the top of the TALOS-3012.

This page intentionally left blank.


## 3 Project Creation

### 3.1 Creating a Project


1. Open CoDeSys IDE and create a Standard Project.



2. Configure the project with “CODESYS Control RTE V3 (3S – Smart Software Solutions GmbH)” PLC programming format.



### 3. Add an EtherCAT master device in the PLC Device tree view.





NOTE:


To enable proper configuration of related PLC and EtherCAT parameters, ensure that both the CoDeSys RTE and Gateway are enabled in the Windows taskbar.



- Connect to CoDeSys gateway and configure the corresponding NIC number in EtherCAT master usage.



5. Add an EtherCAT Device in the device tree, either by scanning the whole EtherCAT line automatically using Scan for Devices, or, alternatively, adding one EtherCAT device manually, recommended to prevent mismatch between physical devices and corresponding ESI file.



6. Set EtherCAT device parameters in the relative device page.

- ▷ **Address Setting:** EtherCAT master will assign the logic slave address automatically, typically starting with 1001 unless the reset manually.
- ▷ **Distributed Clock:** synchronizes all EtherCAT slaves reducing jitter as much as possible.
- ▷ **Sync0:** Among Expert Settings, for fine tuning the behavior of sync manager in dedicated slave setting, with the default setting Disabled, to prevent unexpected synch errors.
- ▷ The remaining settings are among Expert Settings. Contact ADLINK service to adjust the parameters properly.



The screenshot displays the configuration interface for the EtherCAT Master task in the CoDeSys IDE. The left-hand pane shows the project structure, with the 'EtherCAT\_Master (EtherCAT Master)' task selected. The right-hand pane shows the configuration dialog, which is divided into several sections:

- Address:** AutoInc Address is set to 0, and EtherCAT Address is set to 1001.
- Distributed Clock:** Select DC: DC-Synchron. The 'enable' checkbox is checked, and the Sync Unit Cycle is set to 250 µs.
- Sync0:** 'Enable Sync 0' is checked. The 'Sync Unit Cycle' is set to x1, with a Cycle Time of 250 µs and a Shift Time of 0 µs.
- Sync1:** 'Enable Sync 1' is unchecked. The 'Sync Unit Cycle' is set to x1, with a Cycle Time of 250 µs and a Shift Time of 0 µs.
- Station alias:** 'Enable' is checked, and the alias is set to 1001.
- Startup checking:** 'Check Vendor ID' and 'Check Product ID' are checked. 'Check Revision Number' is unchecked.
- Timeouts:** SDO Access is 2000 ms, I->P is 2000 ms, and P->S / S->O is 9000 ms.
- DC cyclic unit control:** 'assign to local µC' is selected. 'Cyclic Unit' and 'Latch Unit 0' are unchecked, while 'Latch Unit 1' is checked.
- Watchdog:** 'Set multiplier (Reg. 16#400)' is 2498, 'Set PDI watchdog (Reg. 16#410)' is 1000 ms, and 'Set SM watchdog (Reg. 16#420)' is 1000 ms.


## 3.2 Starting a Task in CoDeSys IDE Environment

### Start a Task

1. Add a new POU or place an existing POU in the PLC logic tree.
2. Put the POU into task configuration
3. Set the priority of all tasks in task configuration, from 1 (highest) to 31 (lowest).
4. Set PLC polling type and corresponding cycle time (interval period)
5. Enable / Disable PLC watch dog timer (WDT). If no PLC runtime is submitted during a preset time, the WDT will issue a notification to the IDE message box.




The EtherCAT master task occupies the highest priority (0) setting by default, do not reset.



## Build, Log In, and Start the Project

1. Click the “Build” button to compile PLC execution when all POU has been completed.






NOTE:


Ensure that both the CoDeSys RTE and Gateway have been enabled in the Windows taskbar, to allow proper configuration of related PLC and EtherCAT parameters.




2. Click Login/Logout to connect the CoDeSys RTE runtime and IDE.



3. To start or stop the PLC program in RTE runtime, use the Start/Stop buttons or select the commands from the Debug toolbar.




- Run a PLC program in RTE and monitor in IDE. If a green icon is displayed, operations are normal. A red icon indicates an operational abnormality.



### 3.3 Troubleshooting

As mentioned, orange/red icons indicate an error/warning in EtherCAT communication or the failure of EtherCAT slave function. Possible causes are as follows.



Check configuration:

- ▶ Ensure cable connection is secure.
- ▶ Ensure the EtherCAT MAC is properly set.

Master EtherCAT Configuration EtherCAT I/O Mapping Status Information

Autoconfig Master/Slaves **EtherCAT**

**EtherCAT NIC Setting**

Destination Address (MAC) FF-FF-FF-FF-FF-FF  Broadcast  Enable Redundancy

Source Address (MAC) 00-20-9D-EA-10-12 **Browse...**

Network Name Local Area Connection 7

Select network by MAC  Select network by Name

**Distributed Clock**

Cycletime 4000  $\mu$ s

Sync Offset 20 %

Sync Window Monitoring

Sync window 1  $\mu$ s


**Options**

Use LRW instead of LWR/LRD

Enable messages per task


Auto restart slaves

- ▶ Ensure RTE is running:



- ▶ Ensure the EtherCAT slave is connected properly.

- Ensure the EtherCAT Master Task has been properly set:



The screenshot shows the EtherCAT configuration software interface. The 'EtherCAT Configuration' tab is selected, and the 'Autoconfig Master/Slaves' checkbox is checked. The 'EtherCAT NIC Setting' section includes fields for 'Destination Address (MAC)' (FF-FF-FF-FF-FF-FF), 'Source Address (MAC)' (00-20-9D-EA-10-12), and 'Network Name' (Local Area Connection 7). The 'Distributed Clock' section shows 'Cycletime' set to 4000 μs, 'Sync Offset' set to 20 %, and 'Sync window' set to 1 μs. The 'Options' section includes checkboxes for 'Use LRW instead of LWR/LRD', 'Enable messages per task', and 'Auto restart slaves'. The 'Cycletime' field is circled in red.

If the EtherCAT Slave icon is not green, please check the configuration as follows.

- ▶ Ensure that the Basic and Expert settings for EtherCAT slave conform to the specific device requirements.

The screenshot displays the 'EtherCAT Configuration' window with several tabs: 'Slave', 'Expert Process Data', 'Process Data', 'Startup parameters', 'EtherCAT Configuration', and 'EtherCAT'. The 'EtherCAT Configuration' tab is active, showing two main sections: 'Basic' and 'Expert'.

**Basic Settings (indicated by a red box and arrow):**

- Address:** AutoInc Address: 0; EtherCAT Address: 100.1
- Additional:**  Enable Expert Settings;  Optional
- Distributed Clock:** Select DC: DC-Synchron;  enable; Sync Unit Cycle (µs): 4000


**Expert Settings (indicated by a red box and arrow):**

- Sync0:**  Enable Sync 0;  Sync Unit Cycle (x 1, 4000 µs Cycle Time);  User Defined (20 µs Shift Time)
- Sync1:**  Enable Sync 1;  Sync Unit Cycle (x 1, 4000 µs Cycle Time);  User Defined (0 µs Shift Time)
- Startup checking:**  Check Vendor ID;  Check Product ID;  Check Revision Number
- Timeouts:** SDO Access: 1000 ms; I -> P: 6000 ms; P -> S / S -> O: 5000 ms
- DC cyclic unit control:** assign to local µC;  Cyclic Unit;  Latch Unit 0;  Latch Unit 1
- Watchdog:**  Set multiplier (Reg. 16#400): 25000;  Set PDI watchdog (Reg. 16#410): 1000 = 1000.08 ms;  Set SM watchdog (Reg. 16#420): 100 = 100.01 ms
- Station alias:**  Enable; 100.1


- ▶ If an alarm has been issued for the EtherCAT slave, reset the alarm.
- ▶ Ensure that EtherCAT cables are connected properly.

### 3.4 Errors

To identify the error, open the Log tab in the Device page and locate the error listing.




To isolate the error, first check the EtherCAT status in the Diagnostic Message of the Master setting tab.







Then check the EtherCAT status in the Diagnostic Message of the Slave setting tab.



In addition to the default Op mode, the slave state can be set to Init, Pre-Op, and Safe-Op modes.




The error code produced by the slave can be checked in object dictionary 0x60F3, by SDO command in CoDeSys IDE.




### 3.5 RTE Setting


1. Select Control RTE from the taskbar




## 2. Select PLC Configuration



## 3. The PLC Configuration window opens. Select the Scheduler tab.



4. Set the maximum CPU loading (as a percent value).



- Open Task Configuration to monitor task time consumption.

Task	Status	IEC-Cycle Count	Cycle Count	Last Cycle Time (µs)	Average Cycle Time (µs)	Max. Cycle Time (µs)	Min. Cycle Time (µs)	Jitter (µs)	Min. Jitter (µs)	Max. Jitter (µs)
EtherCAT...	Valid	12414	96431	25	22	7954	7	-12	-3821	3766
MainTask	Valid	12414	96431	2	2	18	1	-4	-3851	165

- In the Application context menu, select Add Object and then Trace to show the traced plot link to the variable in the program.

This page intentionally left blank.


# Appendix A PLC Handler

PLC handler manages data exchange between CoDeSys RTE and any Windows executions to support customized visualization with C tools such as Microsoft C#, Microsoft Visual Studio, Borland C and other C-based software tools.


## A.1 In CoDeSys

### A.1.1 Configuring Symbols

1. In the **Application** context menu, select **Add Object** and then **Symbol configuration**.




## 2. Select the desired object



The screenshot shows the 'Task Configuration' window. On the left, a tree view under 'Application' shows 'MainTask' selected and highlighted with a red box. On the right, the 'Symbols' list includes GVL, IoConfig\_Application\_Mappings, IoConfig\_Globals, PLC\_PRG, POU, BPLog, IoDrvEthercatLib, and SM3\_Basic.

## 3. Select relative Variables/POU




The screenshot shows the 'PLC\_PRG' object selected in the 'Task Configuration' window. The 'Symbols' list on the right is expanded to show a table of variables and POU items. The 'en03' variable is highlighted with a red box.

Symbol	Access Rights	Maximal	Attribute	Type
C0_switch_on				BOOL
C1_enable_voltage				BOOL
C2_quick_stop				BOOL
C3_enable_operation				BOOL
C4_new_set_point				BOOL
C5_change_set_imm				BOOL
C6_abs				BOOL
C7_fault_reset				BOOL
C7_fault_reset_2				BOOL
C8_halt				BOOL
dis09				LREAL
en01				BOOL
en02				BOOL
en03				BOOL
en04				BOOL
en05				BOOL



#### 4. Set the Codesys gateway to PLCHandlerGateway3.ini




## A.2 In Windows

Copy the PLCHandlerGateway3.ini file into the corresponding folder for execution.


### A.2.1 Mapping Variables

1. On the DESample tab, select **Create** and then **Connect**.

2. Select **Get All Symbol Name**, corresponding variables are displayed.



3. Select the desired variable and double-click to R/W.



## Appendix B BIOS Setup



NOTE:

BIOS options in the manual are for reference only, and are subject to configuration. Users are welcome to download the latest BIOS version from the ADLINK website.

---

The Basic Input/Output System (BIOS) is a program that provides a basic level of communication between the processor and peripherals. In addition, the BIOS also contains codes for various advanced features applied to the TALOS-3012. The BIOS setup program includes menus for configuring settings and enabling features of the TALOS-3012. Most users do not need to use the BIOS setup program, as the TALOS-3012 ships with default settings that work well for most configurations.

---



WARNING:

Changing BIOS settings may lead to incorrect controller behavior and possible inability to boot.

---

## B.1 Main



### B.1.1 BIOS Information

Shows current system BIOS core version, BIOS version and Board version.

### B.1.2 System Time/System Date

Changes system time and date. Highlight System Time or System Date using the up or down <Arrow> keys. Enter new values using the keyboard then <Enter>. Use < Tab > to move between fields. The date must be entered in MM/DD/YY format. The time is entered in HH:MM:SS format.



NOTE:

The time is in 24-hour format, for example, 5:30 A.M. appears as 05:30:00, and 5:30 P.M. as 17:30:00.

## B.1.3 System Management



### Board Information

Provides SEMA Board Information.

### Temperatures and Fan Speed

Displays system temperatures and fan speed.

### Power Consumption

Provides system power consumption information.


## Runtime Statistics

Displays runtime statistics for the system.

## Flags

Shows SEMA flags.

## Power Up



### Power-Up Watchdog

Resets the system after a preset period after power up has passed.

### ECO Mode

Reduces power consumption of the system. After shutdown, at least 5 seconds must pass before restart can be executed.


## Power-Up Mode

Selecting Turn On starts the device automatically when the power supply is turned on.

Selecting Remain Off starts the device when the power button is pressed.


Selecting Last State powers up to the last power state

## B.2 Advanced



Setting incorrect or conflicting values in Advanced BIOS Setup may cause system malfunction.

## B.2.1 CPU Configuration



### Limit CPUID Maximum

Disabled for Windows XP.

### Execute Disable Bit

XD can prevent certain classes of malicious buffer overflow attacks when combined with a supporting OS (Windows Server 2003 SP1, Windows XP SP2, SuSE Linux 9.2, RedHat Enterprise 3 Update 3.)

### Intel Virtualization Technology


When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology

### Power Technology

Enables power management features.




## Socket 0 CPU Information



Feature	Description
CPU Brand Name	Displays CPU brand name
CPU Signature	Displays CPU signature
Microcode Patch	Displays microcode patch
Max CPU speed	Displays max CPU speed
Min CPU speed	Displays min CPU speed
Processor Cores	Displays processor cores
Intel HT Technology	Displays Intel HT Technology support status
Intel VT-x Technology	Displays Intel VT-x Technology support status

Feature	Description
L1 Data Cache	Displays cache info
L1 Code Cache	Displays cache info
L2 Cache	Displays cache info
L3 Cache	Displays cache info


## CPU Thermal Configuration



### *DTS*

Enables/Disables Digital Thermal Sensor.

## PPM Configuration



### *CPU C state Report*

Enables/Disables reports of CPU C state to OS.


### *Max CPU C-state*

Determines which Max C state the processor supports.

### *S0ix*

Enables/Disables CPU S0ix state

## B.2.2 SATA Configuration



### Serial-ATA (SATA)

Enables/Disables Serial ATA

### SATA Speed Support

Selects SATA Speed Support Gen1 or Gen2

### SATA Mode

Selects IDE/AHCI modes


### Serial-ATA Port 0

Enables/Disables Serial ATA Port 0

## SATA Port0 HotPlug

Enables/Disables Port O HotPlug capability

### B.2.3 USB Configuration



#### Legacy USB Support

Selecting AUTO disables legacy support if no USB devices are connected, and DISABLE keeps USB devices available for only EFI applications.

#### XHCI Hand-Off

A workaround for OSs without XHCI handoff support. XHCI ownership change should be claimed by XHCI driver.

## **EHCI Hand-Off**

A workaround for OSs without EHCI handoff support. EHCI ownership change should be claimed by EHCI driver

## **USB Mass Storage Driver Support**

Enables/disables USB Mass Storage Driver support.

## **USB transfer time-out**

Timeout value for Control, Bulk, and Interrupt transfers.


## **Device reset time-out**

USB mass storage device Start Unit command timeout.

## **Device power-up delay**

Maximum time the device will take before reporting to the Host Controller. Selecting Auto employs the default value, ie for a Root port, 100 ms and for a Hub port the delay is taken from Hub descriptor.

## USB Host Controller Configuration



### XHCI mode

Sets operating mode of XHCI controller.

### USB2 Link Power Management

Enables/disables USB2 Link Power Management.


### USB Per Port Control

Controls each USB port 0 to 3, Enabling USB per port, or Disable by USB port x settings.

### USB Port #0~3

Enables/disables USB Ports 0 to 3.

## B.2.4 SDIO Configuration




### SDIO Access Mode

Selecting Auto accesses SD device in DMA mode if controller supported, otherwise in PIO mode. Selecting DMA accesses SD device in DMA mode, and selecting PIO Accesses SD device in PIO mode.




## B.2.5 Network Configuration



### Network Stack

Enables/disables UEFI Network Stack

## B.2.6 Baytrail Feature Configuration



### LPSS & SCC Devices Mode

Sets LPSS & SCC Device Mode.

### SCC SD Card Support

Enables/Disables SCC SD Card support

### DDR50 Support for SD Card

Enables/Disables DDR50 capability in SD card controller.

### MIPI HSI Support

Enables/Disables MIPI HSI support.


### LPSS HSUART # Support

Enables/Disables LPSS HSUART # support.

## HSUART Port Mode

Sets HSUART port mode.

### B.2.7 ACPI Setting



#### Enable ACPI Auto Configuration

Enables/Disables BIOS ACPI Auto Configuration.

#### Enable Hibernation

Enables/Disables hibernation capability (OS/S4 Sleep State), when supported by OS.


#### ACPI Sleep State

Selects the highest ACPI sleep state the system will enter when SUSPEND is selected.

## Lock Legacy Resources

Enables/Disables Legacy Resource lock.

## B.2.8 Thermal Configuration



### Critical Trip Point

Sets the ACPI critical trip point temperature at which the OS will shut the system down.


### Passive Trip Point

Sets the temperature of the ACPI critical trip point at which the OS will begin throttling the processor

### Active Cooling Trip Point

Sets the Active Cooling trip point.

## B.2.9 Security Configuration



### TXE

Enables/Disables TXE firmware

### TXE HMRFB0

Enables/Disables TXE HMRFB0

### TXE Firmware Update

Enables/Disables TXE firmware update.


### TXE EOP Message

Sends EOP Message Before OS starts up.

### TXE Unconfiguration Perform

Reverts TXE Settings to factory defaults.


## B.2.10 Miscellaneous Configuration



### OS Selection

Selects active OS.

## B.3 Security



NOTE:

If only the Administrator's password is set, only access to Setup is limited and authorization requested only when entering Setup. If only the User's password is set, a password must be entered to boot or enter setup. In Setup the user has Administrator rights.


### Administrator Password

Sets Administrator password.

### User Password

Sets boot/setup User password.

## B.4 Boot



### Setup Prompt Timeout

Sets number of seconds to wait for setup activation key.

### Bootup Num-Lock State

Allows Number Lock setting to be modified during boot.

### Quiet Boot

When Disabled, directs BIOS to display POST messages, when Enabled, directs BIOS to display the OEM logo.

### Fast Boot


Enables or disables boot with initialization of the minimal set of devices required to launch active boot option. Has no effect on BBS boot options.



## Boot Option Priorities

Specifies the priority of boot devices, with all installed boot devices detected during POST and displayed, where selecting Boot Option # specifies the desired boot device.

### CSM Configuration



#### *CSM Support*

Enables/disables CSM support.

#### *GateA20 Active*

Selecting Upon Request allows GA20 to be disabled using BIOS services, and selecting Always disallows disabling of GA20, useful when any RT code exceeding 1MB is executed.

#### *Option ROM Messages*

Sets display mode for Options.

### *INT19 Trap Response*

Sets BIOS reaction to INT19 trapping by Option ROM, where selecting Immediate executes the trap immediately, and Postponed executes the trap during a legacy boot.

### *Boot option filter*

Sets Legacy/UEFI ROM priority.

### *Network*

Sets execution of UEFI and Legacy PXE OpROM.

### *Storage*

Sets execution of UEFI and Legacy Storage OpROM.


### *Video*

Sets execution of UEFI and Legacy Video OpROM.

### *Other PCI devices*

Determines OpROM execution policy for devices other than Network, Storage, or Video.

## B.5 Exit



### **Save Changes and Exit**

Exits Setup after saving changes.

### **Discard Changes and Exit**

Exits Setup without saving any changes.

### **Save Changes and Reset**

Resets the system after saving changes.

### **Discard Changes and Reset**

Resets system setup without saving any changes.

### **Save Changes**

Saves all changes made to Setup options.

## **Discard Changes**

Discards changes made to Setup options.

## **Restore Defaults**

Returns all BIOS options to Default settings, providing maximum system stability with limited performance. Applicable in the event of system configuration problems.

## **Save as User Defaults**

Save changes as User Defaults.

## **Restore User Defaults**

Restores User Defaults to all Setup options.

## **Launch EFI Shell from filesystem device**

Initiates launch of EFI Shell application (Shellx64.efi) from an available filesystem device.

## **Reset System with ME disable ModeMEUD000**

ME runs in temporary disable mode, not applicable if ME Ignition FWMEUD001.

# Important Safety Instructions

For user safety, please read and follow all **instructions**, **WARNINGS**, **CAUTIONS**, and **NOTES** marked in this manual and on the associated equipment before handling/operating the equipment.

- ▶ Read these safety instructions carefully.
- ▶ Keep this user's manual for future reference.
- ▶ Read the specifications section of this manual for detailed information on the operating environment of this equipment.
- ▶ When installing/mounting or uninstalling/removing equipment:
  - ▷ Turn off power and unplug any power cords/cables.
- ▶ To avoid electrical shock and/or damage to equipment:
  - ▷ Keep equipment away from water or liquid sources;
  - ▷ Keep equipment away from high heat or high humidity;
  - ▷ Keep equipment properly ventilated (do not block or cover ventilation openings);
  - ▷ Make sure to use recommended voltage and power source settings;
  - ▷ Always install and operate equipment near an easily accessible electrical socket-outlet;
  - ▷ Secure the power cord (do not place any object on/over the power cord);
  - ▷ Only install/attach and operate equipment on stable surfaces and/or recommended mountings; and,
  - ▷ If the equipment will not be used for long periods of time, turn off and unplug the equipment from its power source.


- ▶ Never attempt to fix the equipment. Equipment should only be serviced by qualified personnel.
- ▶ A Lithium-type battery may be provided for uninterrupted, backup or emergency power.



Risk of explosion if battery is replaced with an incorrect type; please dispose of used batteries appropriately.

- ▶ Equipment must be serviced by authorized technicians when:
  - ▷ The power cord or plug is damaged;
  - ▷ Liquid has penetrated the equipment;
  - ▷ It has been exposed to high humidity/moisture;
  - ▷ It is not functioning or does not function according to the user's manual;
  - ▷ It has been dropped and/or damaged; and/or,
  - ▷ It has an obvious sign of breakage.

Please pay strict attention to all warnings and advisories appearing on the device, to avoid injury or damage.



# Getting Service

Contact us should you require any service or assistance.

## **ADLINK Technology, Inc.**

Address: 9F, No.166 Jian Yi Road, Zhonghe District  
New Taipei City 235, Taiwan  
新北市中和區建一路 166 號 9 樓  
Tel: +886-2-8226-5877  
Fax: +886-2-8226-5717  
Email: [service@adlinktech.com](mailto:service@adlinktech.com)

## **Ampro ADLINK Technology, Inc.**

Address: 5215 Hellyer Avenue, #110  
San Jose, CA 95138, USA  
Tel: +1-408-360-0200  
Toll Free: +1-800-966-5200 (USA only)  
Fax: +1-408-360-0222  
Email: [info@adlinktech.com](mailto:info@adlinktech.com)

## **ADLINK Technology (China) Co., Ltd.**

Address: 上海市浦东新区张江高科技园区芳春路 300 号 (201203)  
300 Fang Chun Rd., Zhangjiang Hi-Tech Park  
Pudong New Area, Shanghai, 201203 China  
Tel: +86-21-5132-8988  
Fax: +86-21-5132-3588  
Email: [market@adlinktech.com](mailto:market@adlinktech.com)

## **ADLINK Technology Beijing**

Address: 北京市海淀区上地东路 1 号盈创动力大厦 E 座 801 室(100085)  
Rm. 801, Power Creative E, No. 1 Shang Di East Rd.  
Beijing, 100085 China  
Tel: +86-10-5885-8666  
Fax: +86-10-5885-8626  
Email: [market@adlinktech.com](mailto:market@adlinktech.com)

## **ADLINK Technology Shenzhen**

Address: 深圳市南山区科技园南区高新南七道 数字技术园  
A1 栋 2 楼 C 区 (518057)  
2F, C Block, Bldg. A1, Cyber-Tech Zone, Gao Xin Ave. Sec. 7  
High-Tech Industrial Park S., Shenzhen, 518054 China  
Tel: +86-755-2643-4858  
Fax: +86-755-2664-6353  
Email: [market@adlinktech.com](mailto:market@adlinktech.com)

## **LiPPERT ADLINK Technology GmbH**

Address: Hans-Thoma-Strasse 11, D-68163  
Mannheim, Germany  
Tel: +49-621-43214-0  
Fax: +49-621 43214-30  
Email: [emea@adlinktech.com](mailto:emea@adlinktech.com)

**ADLINK Technology, Inc. (French Liaison Office)**

Address: 6 allée de Londres, Immeuble Ceylan  
91940 Les Ulis, France  
Tel: +33 (0) 1 60 12 35 66  
Fax: +33 (0) 1 60 12 35 66  
Email: france@adlinktech.com

**ADLINK Technology Japan Corporation**

Address: 〒101-0045 東京都千代田区神田鍛冶町 3-7-4  
神田 374 ビル 4F  
KANADA374 Bldg. 4F, 3-7-4 Kanda Kajicho,  
Chiyoda-ku, Tokyo 101-0045, Japan  
Tel: +81-3-4455-3722  
Fax: +81-3-5209-6013  
Email: japan@adlinktech.com

**ADLINK Technology, Inc. (Korean Liaison Office)**

Address: 137-881 서울시 서초구 서초대로 326, 802 (서초동, 모인터빌딩)  
802, Mointer B/D, 326 Seocho-daero, Seocho-Gu,  
Seoul 137-881, Korea  
Tel: +82-2-2057-0565  
Fax: +82-2-2057-0563  
Email: korea@adlinktech.com

**ADLINK Technology Singapore Pte. Ltd.**

Address: 84 Genting Lane #07-02A, Cityneon Design Centre  
Singapore 349584  
Tel: +65-6844-2261  
Fax: +65-6844-2263  
Email: singapore@adlinktech.com

**ADLINK Technology Singapore Pte. Ltd. (Indian Liaison Office)**

Address: #50-56, First Floor, Spearhead Towers  
Margosa Main Road (between 16th/17th Cross)  
Malleswaram, Bangalore - 560 055, India  
Tel: +91-80-65605817, +91-80-42246107  
Fax: +91-80-23464606  
Email: india@adlinktech.com

**ADLINK Technology, Inc. (Israeli Liaison Office)**

Address: 27 Maskit St., Corex Building  
PO Box 12777  
Herzliya 4673300, Israel  
Tel: +972-54-632-5251  
Fax: +972-77-208-0230  
Email: israel@adlinktech.com

**ADLINK Technology, Inc. (UK Liaison Office)**

Tel: +44 774 010 59 65  
Email: UK@adlinktech.com