

TRP-C34H

Ethernet to 4 RS232/422/485 Converter



User's Manual

Printed Sep. 2013 Rev 1.1

Trycom Technology Co., Ltd
1F, No.2-11, Sihu street, Yingge Township, Taipei, Taiwan ROC
Tel: 886-2-86781191, Fax: 886-2-86781172
Web: www.trycom.com.tw

Copyright

Copyright Notice: The information in this manual is subject to change without notice to improve reliability, design and function and does not represent a commitment on the part manufacturer. No part of this manual may be reproduced, copied, or transmitted in any form, without prior written permission by the manufacturer. Products mentioned in this manual are mentioned for identification purposes only. In this manual, product names appearing may or may not be registered trademarks of their respective companies or copyright.

1. Introduction

TRP-C34H 4 RS232/422/485 Serial Server provides a transparent way of connecting Serial devices over Ethernet. It can transmit data between the Serial and Ethernet interfaces bi-directionally. To establish automatic or remote data acquisition, TRP-C34H solution can easy to connect to 3 TRP-C08X which supports 16 Real-COM/ TCP Port by USB cable with only one IP address.

By specifying the IP address and the TCP Port number, a host computer can access different Serial Devices such as Serial Modems, Serial Thermometers, Magnetic Card Readers, Barcode Scanners, Data Acquisition Systems, POS Terminals, Industrial PCs etc., over the Network, you can centralize Serial Device management and distribute the management to different hosts at the same time. TRP-C34H makes possible to access distant Serial Devices over Network as if they were directly connected to the Standard COM Port of a Personal Computer.

TRP-C34H supports different modes of operation allowing user to operate the system in different environments.

Real COM Mode.

TRP-C34H comes equipped with COM drivers that work with Operating Systems WIN 32bit XP /Vista/2003Server/2008 Server (32-bit & 64-bit), 2000 Server OS, Win 7 (32-bit & 64-bit), The driver establishes a transparent connection between host and serial device by mapping the IP: Port Number of the TRP-C34H's Serial Port to a local COM Port on the host computer.

The important point is that Real COM Mode allows users to continue using RS-232/422/485 serial communications software like HyperTerminal and similar applications.

TCP Server Mode.

In TCP Server mode, TRP-C34H provides a unique IP: Port address on a TCP/IP network. TRP-C34H waits passively to be contacted by the host computer, allowing the host computer to establish a connection with and get data from the serial device. This operating mode supports up to 4 simultaneous connections, so that multiple hosts can collect data from the same serial device—at the same time.

TCP Client Mode.

In TCP Client mode, TRP-C34H can actively establish a TCP connection to a pre-defined host computer when serial data arrives. After the data has been transferred, TRP-C34H can automatically disconnect from the host computer by using the TCP alive check time or Inactivity time settings. This Operating Mode supports establishing the TCP connection up to 4 Destination Hosts.

UDP Mode.

Compared to TCP communication, UDP is faster and more efficient. In UDP mode, you can multicast data from the serial device to multiple host computers, and the serial device can also receive data from multiple host computers, making this mode ideal for message display applications.

TRP-C34H hardware supports wide range power input , the 4 RS422/485 interface with surge, over current ,over voltage protection, the RS485 interface built-in hardware decoder ensure RS485 data without lost, Specify hardware can ensure on line RS485 device working fine.

The TRP-C34H has four synchronous D SUB 9 pin serial port for RS232 connection and 4 screw terminal block for RS422/485 and power connection. The Ethernet port support Auto-MDIX and Auto-select 10/100MB.

When TRP-C34H working at unstable voltage industrial environment, the hardware circuit detection can prevent the power fail cause of the boot fail and Re-Boot.

1-1. Features

- Wide input range DC power supply.
- Supports Socket operation modes like TCP Server, TCP Client, and UDP using TCP/IP and UDP protocols.
- Support Auto-MDIX twisted pair crossover detection and auto-correction.
- Low cost solution and easy to support 6/8/10/12/14/16 RS-232/422/485 Serial Ports.
- Each Port maximum connection 4 host PC at TCP Server and TCP Client Mode.
- External P1/P2/P3 USB port, each port can connect TRP-C08S/C08U/C08H/C08X/C29U.
- Maximum allowed bandwidth is 460 Kbps per Serial Port.
- Supports Web Console, Telnet Console.
- Runs in Stand Alone Mode.
- Built in Restore Factory default push button.
- Features Accessible Imps List to add or remove “legal” remote host IP Addresses to prevent unauthorized access to TRP-C34H.
- Features Auto IP Address Report to periodically report the IP Address of TRP-C34H to the assigned Host on Network.
- Auto direction RS485 flow control by hardware.
- Surge protection and over current and over voltage on RS-422/485 data lines.
- Virtual COM drivers for WIN 32bit XP /Vista/2003Server/2008 Server (32-bit & 64-bit), 2000 Server OS, Win 7 (32-bit & 64-bit).
- Fully compatible with Ethernet and TCP/IP protocol.
- Supports 10/100 Mbps Ethernet.
- Power/Link and 4 pair Serial RX/TX mode LED indicator.

- Support screw terminal and standard external DC power adaptor.
- Din rail or panel mounts support.

1.2. Specification.

- CPU:32 bit 170MHZ with MMU.
- SDRAM:32MB.
- FLASH:8MB.
- Power Input Voltage: DC +10V to +30V.
- LAN: Auto-MDIX, 10/100 Mbps Auto-detecting.
- RS-232: RI, TX, RX, RTS, CTS, DTR, DSR, DCD, GND.
- RS-422: TX+, TX-, RX+, RX-.
- RS-485: Data +, Data –.
- Data Rate: 75~921Kbps.
- Parity: none, even, odd.
- Data Bits: 5, 6, 7 or 8.
- Stop Bits: 1, 1.5 or 2.
- Configuration through Windows Admin Utility / Web Console / Telnet Console.
- Supports Real COM mode using RFC 2217 protocol.
- Protocol: ICMP, TCP/IP, UDP, DHCP, Boot, Telnet, DNS, SNMP, HTTP, SMTP, SNTP.
- External P1/P2/P3 Port, each port can be connecting item below.

[TRP-C08S](#) :USB to 1 RS232 and 1 RS422/485 Isolated Converter.

[TRP-C08H](#) :USB to 2 RS232 and 2 RS422/485 Isolated Converter.

[TRP-C08U](#) :USB to 4 RS232 Isolated Converter.


[TRP-C08X](#) :USB to 4 RS232/422/485 Converter.

[TRP-C29U](#):USB to 8 Digital Input and 8 Digital Output Remote I/O.

- Power supply: Screw terminal, or standard external DC adapter.
- External P1, P2, P3 connector: USB A Type, support power consumption: 500mA/5V.
- Serial interface: +/-15 KV ESD.
- RS422/485 interface: Surge, over current, over voltage protection.
- Power consumption: 12V/450 mA (without external device).
- Operating Temperature: 0 to 65 °C.
- Humidity: 0~90% Non-Condensing.
- Dimensions: 145(L)*118(W)*26(H) /mm.
- Weight: 728g (W/Packing).

1-3. TRP-C34H Supports 3 TRP-C08X Diagram.

TRP-C34H is a system level solution with four RS232/422/485 serial ports connected to three TR-C08X to supports 16 serial port interfaces,TRP-C08X connected to any of the P1/P2/P3 Ports of TRP-C34H to supports 8/12/16 Serial Port interfaces. Each TRP-C08X can provide four RS232/RS422/RS485 Serial Ports.



1-4. TRP-C34H Supports TRP-C08X/C08S/C08H/C08U/C29U Diagram.


TRP-C08X/TRP-C08H/TRP-C08U/TR-C29U connected to any of the P1/P2/P3 USB Ports of TRP-C34H to supports 6/8/10/12/14/16 Serial Port interfaces or Maximum 24 Channel I/O with TRP-C29U.

TRP-C34H with TRP-C08X/TRP-C08S/TRP-C08H/TRP-C08U/TRP-C29U



2. Hardware Description.

2-1. Panel layout and Dimension.



mm/Unit.

Please note: the Power Adaptor need to provide sufficient current and voltage, the proposed purchase of the original Power Switching 12V / 1A transformer, low current will cause unpredictable hardware error!

12-2. LED indicators.

2PWR LED: Blinking: Not Ready.

3 ON: Stand By.

LINK LED: Ethernet cable connection and data active.

TX/RX LED: COMA~COMD RS232/422/485 Transmitting/Receiving Indicator.

DC Jack: Power Input DC +10V to +30V. (Please use the 5.5*2.1mm DC JACK).

12-3. Factory default.

*** Push the factory restore button till the PWR LED off and then reboot.**

Hardware Setting: COMA~COMD: RS232.

Unlock Password: trycom.

Model Name: SerialServer 4S.

Basic configuration:

The screenshot shows the 'Basic Settings' tab of a web configuration interface. It contains several sections for configuration:

- Server Name:** A text input field containing 'trycom' with a 'Modify' checkbox.
- Inactivity Time:** A section with an 'Enable' checkbox and an input field for 'Inactivity Time' in seconds.
- Time Zone:** A dropdown menu set to '(GMT+05:30) India' with a 'Modify' checkbox.
- Local Date:** A dropdown menu set to '1/ 1/1970' with the word 'Option' written in red next to it and a 'Modify' checkbox.
- Local Time:** Three input fields for 'Hr(s)' (8), 'Min(s)' (0), and 'Sec(s)' (41).
- TimeServer:** An empty text input field.
- Console Settings:** A section with 'Enable Web Console' and 'Enable Telnet Console' checkboxes, both of which are checked.

IP setting:

Accessible IPs	Auto Warning	IP Address Report	Password
Basic Settings	IP Settings	Port Settings	Operating Mode
<input type="checkbox"/> Modify IP Address : 192 . 168 . 3 . 22			
<input type="checkbox"/> Modify Net Mask : 255 . 255 . 255 . 0 Gateway : 192 . 168 . 3 . 1 IP Configuration : Static DNS Server1 : . . . DNS Server2 : . . .			
<input type="checkbox"/> Modify <input checked="" type="checkbox"/> Enable SNMP Community Name : public Location : Contact :			
<input checked="" type="checkbox"/> Modify Subnet 2 : . . . Gateway 2 : . . .			

Port Setting:

Port 1~4:115200bps,8-bit,None,RS232

Operating Mode:

Real Com Mode.

Accessible IPs:

None Setting.

Auto Warning:

None Setting.

IP Address Report:


None Setting.

Password:

Factory: trycom

12-4. DIP Switches.

Steel side with a switch can be adjusted to each COM PORT RS232 or RS422/485.




*Please use screwdriver and then open back of metal, adjust the switch to select RS232 or RS422/485.


2-5. Push Button.

If lost the password or IP, user can keep push button for restore factory default till the PWR LED off and then reboot.

12-6. Four RS232 D-SUB male PIN assignments.



12-7. Four RS422/485 Screw Terminal assignments.



3. Installing TRP-C34H Hardware.

STEP1: Please use screwdriver and then open back of metal, adjust the switch to select RS232 or RS422/485 function.

STEP2: Connect the power source from DC-Jack or screw terminal, the PWR LED will blinking, wait till boots PWR LED ON.

STEP3: Connect TRP-C34H with Ethernet port by RJ45 cable.

If the cable is properly connected the "LINK" LED will light up.


*The TRP-C34H Supports Auto-MDIX, A straight-through or crossover RJ45 cable can be used to make a connection directly to the HUB/Router/PC LAN port.

STEP4: Connect TRP-C34H to RS232 device by Null-Modem cable.

Connect TRP-C34H to RS422/485 by AWG #12~30 twisted pair wires.


3-1. RS485 Wiring.

The RS-485 mode supports the Transmit and Receive channels use twisted pair wire half-duplex operation.




3-2. RS422 Wiring.

The RS-422 mode supports 4 channels with full duplex operation use dual twisted pair wire half-duplex operation.



3-3. RS232 Wiring.


Refer to the Pin out table for connections.



4. How to configure TRP-C34H.

There are 3 ways to access the TRP-C34H.

a. Serial Server Admin Utility.




1b. WEB Server.

Serial Server Web Console - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Back Forward Stop Home Search Favorites Refresh Print Mail

Address http://192.168.3.22/cgi-bin/script.cgi/session=1&filename=database1&formno=1



www.trycom.com.tw

Welcome to Serial Server's web console

Model Name	SerialServer4S
MAC Address	00:50:C2:1B:7F:01
Serial No.	16
Firmware version	1.24_15NOV10

Serial Server is a 4SP Device
This web console provides the following function groups

- Basic Settings**
Server name, real time clock, time server IP address, and web console, disable function.
- Network Settings**
IP address, netmask, default gateway, static IP or dynamic IP, DNS, SMTP
- Serial Settings**
Baud rate, parity, data bits, stop bits, flow control, interface.
- Operating Settings**
Operation mode, TCP alive check, inactivity.
- Accessible IP settings**
"Accessible IP or Accessible IP group".Disable to accept all IP's connection.
- Auto Warning Settings**
Auto Warning Settings

Main menu

- Overview
- Basic Settings
- Network Settings
- Serial Settings
- Operating Settings
- Accessible IP Settings
- Auto Warning Settings
- Change Password
- Load Factory Default
- Upgrade
- Save/restart
- Logout

c. Telnet.

```

Telnet 192.168.3.22
-----
Model Name       :SerialServer4S
MAC Address      :00:50:C2:1B:7F:01
Serial Number    :16
Firmware Version :1.24_15NOV10
-----

<<Main Menu>>
(1) Basic Settings
(2) Network Settings
(3) Serial Settings
(4) Operating Settings
(5) Accessible IP Settings
(6) Auto Warning Settings
(7) Monitor
(8) Ping
(9) Password Settings
(a) Load Factory Defaults
(v) View Settings
(s) Save/Restart
(q) Quit

Key in your selection:
  
```

4-1. Installing Serial Server Admin Utility.


The "Serial Server Admin Utility" Support WIN XP/VISTA/2003 Server/2008 Server 32/64 bit, 2000 Server/Win 7.

Insert the TRP-Serial CD, find the TRP-C34H's folder"Utility" and run "PortSetup.exe"

When Installation is completed the wizard creates a Serial Server Admin Utility shortcut on the Desktop as shown below.



Double Click on the Serial Server Admin Utility then Right click on the main window or go to Server Manager in Menu Bar and select Search Devices to find the TRP-C34H on the network.




By default all the devices searched are locked and can be seen under the status column of the Server Manager Window in order to protect from unauthorized configuration changes.


In order to configure the device, it has to be Unlocked first. Unlock password: **trycom**

After the device has been Unlocked, the device can be configured for all Network, Serial, Operating settings. Select the device to be configured, Right Click on the selected device and

click on configure to go to Configuration menu. (Double clicking on selected device can also open the Configuration menu).



This invokes the Server Manager Configuration Dialog as shown below.




On Basic page, check the Modify check Box to change any of the Configuration details.

IP Setting:

Accessible IPs	Auto Warning	IP Address Report	Password
Basic Settings	IP Settings	Port Settings	Operating Mode
<input type="checkbox"/> Modify IP Address : <input type="text" value="192 . 168 . 3 . 22"/>			
<input type="checkbox"/> Modify Net Mask : <input type="text" value="255 . 255 . 255 . 0"/> Gateway : <input type="text" value="192 . 168 . 3 . 1"/> IP Configuration : <input type="text" value="Static"/> <input type="button" value="v"/> DNS Server1 : <input "="" "."="" .="" type="text" value="."/> DNS Server2 : <input "="" "."="" .="" type="text" value="."/>			
<input type="checkbox"/> Modify <input checked="" type="checkbox"/> Enable SNMP Community Name : <input type="text" value="public"/> Location : <input type="text"/> Contact : <input type="text"/>			
<input checked="" type="checkbox"/> Modify Subnet 2 : <input "="" "."="" .="" type="text" value="."/> Gateway 2 : <input "="" "."="" .="" type="text" value="."/>			

On IP Settings Page, click the modify box first, you can modify all the Network parameter

- a. IP address
- b. Net Mask
- c. Gateway
- d. Click the IP Configuration drop-down box, to modify the parameter Static/DHCP/BOOTP.




- e. DNS Server 1: When the user wants to visit a particular website, the computer asks the Domain Name System (DNS) Server for the website's correct IP address, and the computer uses the response given by DNS Server to connect to the Web Server. DNS is the way that Internet Domain Names are identified and translated into IP address.
- f. DNS server 2: An optional alternative of DNS Server.
- g. Community Name: A community name is a plain-text password mechanism that is used to weekly authenticate queries to agents of managed network devices.
- h. Contact: The SNMP contact information usually includes an emergency contact name and telephone or pager or Mobile number.
- i. Location: This string is usually set to the street address where the TRP-C34H is physically located.

Port Settings Page

On the Port Settings page of the Server Manager dialog displays all the serial ports, present on the Serial Server model of the selected device. It also shows the corresponding serial settings in the settings column of the page

In order to see the current settings of any Serial port, select the port number in above window & then click on View settings.


To modify the serial settings check the modify box on the serial page. Then "View settings" tab would be converted into "Settings" tab as below:



Select any port and click on “View Settings” tab which shows the “Operating Mode” dialog Box as shown below. The default operating Mode is “Real Com” Mode.


Note. TRP-C34H will restart automatically, after configuring the Operating Settings page. For all other pages, TRP-C34H will not restart.

If modify check box is checked to activate the parameter, double click or highlight and click “Settings” tab of the specific port to modify the operating mode. Click the Operating Mode drop-down box to set the Real Com Mode / TCP Server Mode /TCP Client Mode / UDP Mode as shown below.




Real COM Mode

Key in the TCP Alive Check Timeout to set the timeout for TCP Alive time. The Default setting is 7 min. TRP-C34H automatically closes TCP connection if there is no TCP activity for the given time. After the connection is closed, TRP-C34H starts listening for another REAL COM driver’s connection form another host.




TCP Server Mode

- Local TCP Port: The TCP Port of TRP-C34H that uses to listen to the requests coming from Host Computers on Network in order to establish connection. The Host Computers should contact this Port in order to establish connection with the TRP-C34H.
- Click the Max Connection drop-down box to set Max connection options to 1 / 2 / 3 / 4.
- TCP Alive Check Timeout (Default setting is 7 min).
- Inactivity Timeout (Default setting is 0 ==> Disabled).




TCP Client Mode

- Click the Connect Mode drop-down box to set "Startup"/ "Any character".
- Setting Destination IP address 1 and Port Number, allows TRP-C34H to connect actively to the remote host whose address is set by this parameter.
- Similarly Destination IP addresses 2 / 3 / 4, allows TRP-C34H to connect actively to the remote hosts whose address is set by this parameter.
- TCP Alive Check Timeout (Default setting is 7 min)
- Inactivity Timeout (Default setting is 0 ==> Disabled).




UDP Mode

- a. Local Listen port: The UDP port that uses to listen to Data from multiple host computers and also to multicast data to multiple host computers.
- b. UDP Mode Setting Destination:
- c. Destination IP address 1 / 2 / 3 / 4




Accessible IP's Page

Accessible IP settings allow you to add or remove “legal” remote host IP address to prevent unauthorized access to TRP-C34H. Hosts that are included in this list can only access the TRP-C34H on the network.



On “Accessible IP’s” page , click the modify box to activate the parameter, Click on settings button to enter the IP Address and Net Mask of remote host that control the TRP-C34H .



You can allow one of the following cases by setting the parameter.


- Only one host of specific IP address can access the TRP-C34H. Enter “IP address/255.255.255.255” (e.g., “192.168.2.246/255.255.255.255”).
- Hosts on the specific subnet can access the TRP-C34H. Enter “IP address/255.255.255.0” (e.g., “192.168.2.0/255.255.255.0”).
- Any host can access the TRP-C34H. Disable this function by unchecking the “Enable” Check Box.

Refer the following table for more details about the configuration example.

Allowable Hosts	Input format
Any host	Disable
192.168.2.246	192.168.2.246 / 255.255.255.255
192.168.2.1 to 192.168.2.254	192.168.2.0 / 255.255.255.0
192.168.0.1 to 192.168.255.254	192.168.0.0 / 255.255.0.0
192.168.2.1 to 192.168.2.128	192.168.2.0 / 255.255.255.128
192.168.2.129 to 192.168.2.254	192.168.2.128 / 255.255.255.128


Auto Warning Page

Auto warning mechanism is a useful mechanism which sends the status messages to E-Mail id’s and Trap Servers in order to warn or acknowledge the changes made to the TRP-C34H .




On Auto warning page under E-mail and SNMP Trap Setting Tab, click the modify box to activate the parameter.


- a. On Mail server frame, input the IP Address or Domain Name of the Mail server.
- b. Input the From E-mail Address.
- c. Enter the email addresses in the To E-Mail address boxes (1, 2, 3, 4) to whom the acknowledgement has to be sent.
- d. If the Mail Server has to be authenticated, check the Modify box and check the “Mail Server authentication check box”, and then press Setup button
- e. Input the User Name and Password to modify the Mail Server Authentication Setup.



- f. To set or modify the Trap Server , check the Modify checkbox and enter the IP Address or Domain name of the Trap Server to which the Auto warning are to be sent.



On Auto warning page, under Event Tab, click the Modify box to activate the parameter, and click the checkbox to set the Events for which Auto warnings are to be sent.



To get Auto Warning E-Mails:

- i) Give the Mail Server IP address & authentication if required.
- ii) Give from ID & To ID
- iii) Select on what event you want to be notified by mail in "Eventtype" page.


To get Auto Warning Trap Messages,

- i) Key in the IP address of the Linux Machine Trap server option.
- ii) In Network settings page enable SNMP and provide community name, contact, and location information.
- iii) Run this command on Linux PC "snmptrapd -f -Le".
- iv) Select the event type which you want to be notified.


v) On that event notice that some messages will get printed on the console where you are executing the above snmptrapd command.

IP Address Report Page

Network management becomes difficult when TRP-C34H is forced into DHCP. Any IP changes due to DHCP in TRP-C34H are reported to the assigned Host on the Network.



On IP address Report, click the modify box to activate the parameter, and set the IP address, Port number and time period to Auto report to host.



The default Port number is 4002 and the default Auto Report Period is 10 s.


Password

Password can be set / modified & Disabled through this screen. Maximum length of 7 characters can be supported for TRP-C34H password. Alpha, Numeric & Alpha numeric type of passwords are supported.

Space is not allowed between any characters in password.

4-2. using the WEB Server mode.

TRP-C34H support web console for remote configuration of the TRP-C34H on the network. To view the web console, open any web browser (eg., Internet Explorer) and type the IP address in the address bar of the browser. A login form prompting for password appears. Login to the web console by **entering** the correct password and click submit. Default Password is “trycom”.




4-3. Telnet.

TRP-C34H implements a **Telnet Server** and can be invoked by making a Telnet from remote PC. In the “Basic Settings” page of “Windows Configuration Utility”, if the ‘**Enable Telnet Console**’ check box is enabled we can use the Telnet Console to modify the device parameters.

Go to **Start Menu > Run**

Run Telnet from remote pc with the IP address of TRP-C34H as shown below:



5. Application.

5-1. Real COM Mode.

TRP-C34H Basic 4 Real COM Port installs.




Example:


Step1: Connect PC----RJ45----TRP-C34H----RS232/422/485 Device.

Step2: Run "Serial Server Admin Utility" and Right Click on the selected device and click on configure to go to Configuration menu.


Step3: Be sure "IP Setting"," Port Setting" and "Operating Mode" is correct.




Step4: Select "Port Mapping" then right clicks "Add Device".



Step5: The Port Mapping will show below.




Step7: Right Click select "Apply Change".





Step7: The TRP-C34H Real COM Mode setting OK.

***Notice: No matter how to change "Add device" or "Remove Device", its need to be run "Apply change" for save COM Port configuration.**



Step8: plug in RS232 LOOP back connector.




**Look Back Test DB 9 Female
Short PIN1,4,6 PIN 2,3 PIN 7,8**

Step9: Run the "TRPCOM.EXE" utility.

Step10: Click the "Setting" to set the com port and baud rate then press OK .

*Please note: "COM2" is an example of COM port number; the real COM number is assigned by user PC.

Step11: Click the "Terminal" then select Loop back enable, the counter value and pass value will be synchronized counts.




Description

The Terminal Function:

1. Test RS485: Send the command and get RS485 device response.
2. Test RS232/422: RS232(with hardware control) or RS422 loop back wiring.

5-1-1.Appendix: Easy to support multi-ports.

TRP-C34H supports 1/2/3 TRP-C08X up to 8/12/16 COM Port.



1

Step1: Power off the TRP-C34H and then connect TRP-C08X.

Step2: Power on the TRP-C34H will auto detection and configuration.

Step3: All operator steps same 5-1.

Serial Server Admin Utility

File Function Port Mapping View Help


Port Mapping - 16 Port(s)

No	Model	IP Address	TCP Port	COM Number
1	SerialServer16S	192.168.3.22	1234	COM5
2	SerialServer16S	192.168.3.22	1235	COM6
3	SerialServer16S	192.168.3.22	1236	COM7
4	SerialServer16S	192.168.3.22	1237	COM8
5	SerialServer16S	192.168.3.22	1244	COM17
6	SerialServer16S	192.168.3.22	1245	COM18
7	SerialServer16S	192.168.3.22	1246	COM22
8	SerialServer16S	192.168.3.22	1247	COM23
9	SerialServer16S	192.168.3.22	1254	COM24
10	SerialServer16S	192.168.3.22	1255	COM25
11	SerialServer16S	192.168.3.22	1256	COM26
12	SerialServer16S	192.168.3.22	1257	COM27
13	SerialServer16S	192.168.3.22	1264	COM28
14	SerialServer16S	192.168.3.22	1265	COM29
15	SerialServer16S	192.168.3.22	1266	COM30
16	SerialServer16S	192.168.3.22	1267	COM31

Server Manager
Server Monitor
Port Monitor
Port Mapping
Auto IP Address Report

Ready 1/1/2002 03:36:17

5-2. TCP Server Mode.




Example:

Step1: Connect Host PC 1~4 -----Ethernet-----TRP-C34H-----PC .


Step2: Run “Serial Server Admin Utility” and Right Click on the selected device and click on configure to go to Configuration menu.

Step3: Be sure “IP Setting,” Port Setting” and “Operating Mode” is correct.




Step4: Select “Server Monitor” then right clicks “Add Device”.


Step5. Select “Go”.




- Step5. Connect PC COM Port link TRP-C34H COMA~COMD by NULL-Modem Cable.
- Step6. RUN "Demo.exe" and select correct baud-rate and data format.
- Step7. RUN "Telnet.exe" and input IP and Port.




1 Serial Device to 4 TCP Host PC at Same Time Broadcast



5-3. Paired Mode.




Example:




Step1: Run "Serial Server Admin Utility" and Right Click on the selected device and click on configure to go to Configuration menu.

Step3: Be sure "IP Setting," Port Setting" and "Operating Mode" is correct.


Step4: TRP-C34H Client setting, Select "Operating Mode" and then double click Port1~Port4 item same below.




c. Port 3 Setting.




d. Port 4 Setting.




b. Port 2 Setting.



c. Port 3 Settings.



c. Port 4 Setting.




Step6: Keep the TRP-C34H Server in LAN. Also keep the Client PC in LAN.

Step7: **Power ON the TRP-C34H Server and wait till it completely boots PWR LED ON first.**


Step8: Power ON the TRP-C34H Client and wait till it completely boots PWR LED ON.

- Step9: Connect PC COM Port link TRP-C34H Client COMA~COMD by NULL-Modem Cable.
- Step10: Plug in TRP-C34H server COMA~COMD by DB-9 loop back connector.
- Step11: Run the “TRPCOM.EXE” utility.
- Step12: Click the “Setting” to set the com port and baud rate then press OK .




*Please note: “COM2” is an example of COM port number; the real COM number is assigned by user PC.

Step11: Click the "Terminal" then select Loop back enable, the counter value and pass value will be synchronized counts.



6. TRP-C34H Application Diagram.


TCP or Real COM Mode




Paired Mode




1 TCP Client to 4 TCP Server Broadcast



1 Serial Device to 4 TCP Host PC at Same Time Broadcast



TRP-C34H up to 16 Real COM or 16 TCP Port (only one IP)



TRP-C34H with TRP-C08X/TRP-C08S/TRP-C08H/TRP-C08U/TRP-C29U



APPENDIX

The factory default value for **TCP Alive check time** = 7 minutes.

- ❖ If you configure this option to “0 min”, the TCP connection will not be closed due to an idle TCP connection.
- ❖ If you set this option with any value in between “1 to 99 mins”, Serial Server automatically closes the TCP connection if there is no TCP activity for the given amount of time. After the connection is closed, Serial Server starts listening for the TCP connection from another host.

- ✓ Likewise, the factory default value for **Inactivity time** = **0 ms**.
- ✓ If the Inactivity time = 0 ms, the TCP connection will not be closed due to an idle serial line.
- ✓ If you set this option with any value in between “**0-65535 ms**”, Serial Server automatically closes the TCP connection if there is no serial data activity for the given amount of time. After the connection is closed, Serial Server starts listening for the TCP connection from another host.