


RS4232-8 box is your final serial port interface solution

1. RS4232-8 box can support 8 sets RS232 interface to ground isolated RS422/RS485 interface.
2. You just need to set DIP switch to assign your target interface type for each serial port separately.
3. You can use R803 cable between any RAYON's eight port card (ex, P588U card) and RS4232-8 box to let one PC have 8 ground isolated RS422, RS485 interface available.



4. You can use R802 cable to connect with RS4232-8 box. So we can have 8 set RS232 to ground isolated RS422,RS485 interface convertor available. R802 cable will support 8 DB25 female connector for common ground RS232 input.

