# Quick Installation Guide

# Introduction

The TGPS-9164GT-M12 series is a managed Gigabit Ethernet switch with 16 Gigabit PoE-enabled ports and 4 Gigabit non-PoE ports in M12 connector. The series consists of -BP2 models (TGPS-9164GT-M12-BP2) and non-BP2 models (TGPS-9164GT-M12). The non-PoE ports of TGPS-9164GT-M12-**BP2** provide bypass functions to ensure constant network connectivity when power outage or node failure occurs. The switch supports various Ethernet redundancy protocols such as O-Ring (recovery time < 30ms over 250 units of connection), Open-Ring, O-Chain, MRP and MSTP (RSTP/STP compatible) to protect your mission-critical applications from network interruptions or temporary malfunctions. With EN50155 compliance and M12 connectors, the device is a perfect choice for rolling stock applications.

# Package Contents

The device is shipped with the following items. If any of these items is missing or damaged, please contact your customer service representative for assistance.

| Contents  | Pictures   | Number |
|---|--|--------|
| TGPS-9164GT-M12/<br>TGPS-9164GT-M12-24V/<br>TGPS-9164GT-M12-BP2/<br>TGPS-9164GT-M12-BP2-24V | 2 (10000)<br>2 (10000)<br>2 (10000)<br>2 (10000)   | 1      |
| СD  | Control of the Contro | 1      |
| QIG   |  | 1      |

# Preparation

Before you begin installing the device, make sure you have all of the package contents available and a PC with Microsoft Internet Explorer 6.0 or later, for using web-based system management tools.

# Safety & Warnings



Elevated Operating Ambient: If installed in a closed environment, make sure the operating ambient temperature is compatible with the maximum ambient temperature (Tma) specified by the manufacturer.



Reduced Air Flow: Make sure the amount of air flow required for safe operation of the equipment is not compromised during installation.




Mechanical Loading: Make sure the mounting of the equipment is not in a hazardous condition due to uneven mechanical loading.





Circuit Overloading: Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing

# TGPS-9164GT-M12 Series

### Dimension








# Panel Layouts

### Front View



- 1. Reset button
- 2. Power1 status LED
- 3. Power2 status LED
- 4. R.M. status I FD 5. Ring status LED
- 6. Fault LED
- 7. Power connector
- 8. Non-PoE Gigabit Ethernet ports (with bypass -BP2 model)
- 9. PoE-enabled Gigabit Ethernet ports 10. Link/ACT LED for non-PoE Gigabit ports
- 11. Speed LED for non-PoE Gigabit ports
- 12. Link/ACT LED for PoE-enabled Gigabit
- 13. PoE indicator for PoE-enabled Gigabit ports 14. Speed LED for PoE-enabled Gigabit ports
- 15. Console port
- 16. Relay output port

# Installation

# Wall-mount

The device can be fixed to the wall. Follow the steps below to install the device on the wall. Step 1: Hold the device upright against the wall

Step 2: Insert four screws through the large opening of the keyhole-shaped apertures at the top and bottom of the unit and fasten the screws to the wall with a screwdriver. Step 3: Slide the device downwards and tighten the four screws for added stability.



Instead of screwing the screws in all the way, it is advised to leave a space of about 2mm to allow room for sliding the switch between the wall and the screws.

### Wiring

For pin assignments of power, console and relay output ports, please refer to the following tables.

EN50155 20-port managed

**Gigabit PoE Ethernet switch** 

Grounding and wire routing help limit the effects of noise due to electromagnetic interference (EMI). Run the ground connection from the grounding pin on the power connector to the grounding surface prior to connecting devices.

### Power port pinouts

The device supports two sets of power supplies and uses the M23 5-pin female connector on the front panel for dual power inputs. Step 1: Insert a power cable to the power connector on the device Step 2: Rotate the outer ring of the cable connector until a snug fit is achieved. Make sure the connection is tight.





## Console port pinouts





## Relay output port pinouts

The switch uses the M12 A-coded 5-pin female connector on the front panel for relay output. Use a cable with an M12 A-coded 5-pin male connector to connect the relay. The relay contacts will detect user-configured events and form an close circuit when an event is triggered.





# Network Connection

The switch has sixteen 10/100/1000Base-T(X) PoE and four 10/100/1000Base-T(X) non-PoE Ethernet ports in the form of M12 connector. Depending on the link type, the switch uses CAT 3, 4, 5,5e UTP cables to connect to network devices (PCs, servers, switches, routers, or hubs). Please refer to the following table for cable specifications.

| Cable      | Туре                       | Max. Length          | Connector          |
|------------|----------------------------|----------------------|--------------------|
| 10BASE-T   | Cat. 3, 4, 5 100-ohm       | UTP 100 m (328 ft)   | 8-pin female M12   |
| TODASE-1   | Cat. 5, 4, 5 100-01111     | 01P 100 III (328 II) | A-coding connector |
| 100BASE-TX | Cat. 5 100-ohm UTP         | UTP 100 m (328 ft)   | 8-pin female M12   |
| TOORASE-IX |                            |                      | A-coding connector |
| 1000BASE-T | Cat. 5/Cat. 5e 100-ohm UTP | UTP 100 m (328 ft)   | 8-pin female M12   |
|            |                            |                      | A-coding connector |

For pin assignments of the Ethernet ports, please refer to the following tables.





| 8-Pin Gigabit Non-PoE Port |                   |  |  |
|----------------------------|-------------------|--|--|
| Definition                 |                   |  |  |
| PIN Definition             |                   |  |  |
| 1                          | BI_DC+            |  |  |
| 2                          | 2 BI_DD+          |  |  |
| 3                          | BI_DD-            |  |  |
| 4                          | BI_DA-            |  |  |
| 5                          | BI_DB+            |  |  |
| 6                          | BI_DA+            |  |  |
| 7                          | BI_DC-            |  |  |
| 8                          | BI_DB-            |  |  |
|                            | PIN 1 2 3 4 5 6 7 |  |  |

| Definition |                       |  |
|------------|-----------------------|--|
| PIN        | Definition            |  |
| 1          | BI_DC+                |  |
| 2          | BI_DD+                |  |
| 3          | BI_DD-                |  |
| 4          | BI_DA- with PoE Vout+ |  |
| 5          | BI_DB+ with PoE Vout- |  |
| 6          | BI_DA+ with PoE Vout+ |  |
| 7          | BI_DC-                |  |
| 8          | BI_DB- with PoE Vout- |  |
|            |                       |  |

8-Pin Gigabit PoE Port



# ${f Q}$ uick ${f I}$ nstallation ${f G}$ uide

# Configurations

After installing the switch and connecting cables, the green power LED should turn on. Please refer to the following tablet for LED indication.

| LED           | Color                                     | Status   | Description  |  |
|---------------|---|----------|--|--|
| PW1           | Green                                     | On       | DC power module 1 activated                              |  |
| PW2           | Green                                     | On       | DC power module 2 activated                              |  |
| R.M           | Green                                     | On       | Device operating in Ring Master mode                     |  |
| Ring          | Green                                     | On       | Ring enabled   |  |
|               |   | Blinking | Ring structure is broken                                 |  |
| Fault         | Amber                                     | On       | Errors occur (i.e. power failure or port malfunctioning) |  |
| 10/100/1000Ba | 10/100/1000Base-T(X) P.S.E Ethernet ports |          |  |  |
| LNK/ACT       | Green                                     | On       | Port is linked   |  |
| LINK/ACT      |   | Blinking | Transmitting data  |  |
| PoE           | Green                                     | On       | Power supplied over Ethernet                             |  |
|               | Green                                     | On       | Port is running at 1000Mbps                              |  |
| Speed         | Amber                                     | On       | Port is running at 100Mbps                               |  |
|               | Green/Amber                               | Off      | Port is running at 10Mbps                                |  |
| 10/100/1000Ba | ase-T(X) Ethern                           | et ports |  |  |
| LNK/ACT       | Green                                     | On       | Port is linked   |  |
|               |   | Blinking | Transmitting data  |  |
| Speed         | Green                                     | On       | Port is running at 1000Mbps                              |  |
|               | Amber                                     | On       | Port is running at 100Mbps                               |  |
|               | Green/Amber                               | Off      | Port is running at 10Mbps                                |  |

Follow the steps below to log in and access the system:

1. Launch the Internet Explorer and type in IP address of the device. The default static IP address is 192,168,10,1



2. Log in with default user name and password (both are admin).



3. After logging in, you should see the following screen. For more information on configurations, please refer to the user manual. For information on operating the device using ORing's Open-Vision management utility, please go to ORing website.



# TGPS-9164GT-M12 Series

# EN50155 20-port managed **Gigabit PoE Ethernet switch**

## Resetting

To restore the device configurations back to the factory defaults, press the Reset button for a few seconds. Once the power indicator starts to flash, release the button. The device will then reboot and return to factory defaults.

# Specifications

| ORing Switch Model   | TGPS-9164GT-M12   | TGPS-9164GT-M12-24V  | TGPS-9164GT-M12-BP2                                    | TGPS-9164GT-M12-BP2<br>-24V                                 |
|--|---|--|--|---|
| Physical Ports   |   |  |  |   |
| 10/100/1000 Base-T(X) Ports<br>in M12 Auto MDI/MDIX with<br>P.S.E. | 16 x M12 connector (8 pin A-coding)   |  |  |   |
| 10/100/1000Base-T(X) ports<br>in M12                               | 4 x M12 connector (8-pin A-coding)  4 x M12 connector (8-pin A-coding with 2 x bypass function included)  |  |  |   |
| Technology   |   |  |  |   |
| Ethernet Standards   | IEEE 802.3 for 10Base-T IEEE 802.3 io for 10Base-TX IEEE 802.3 io for 100Base-TX IEEE 802.3 io for 100Base-T IEEE 802.3 io for 1000Base-T IEEE 802.3 io for IACP (Link Aggregation Control Protocol) IEEE 802.1 io for COS (Class of Service) IEEE 802.1 io for VLAN Tagging IEEE 802.1 iv for VLAN Tagging IEEE 802.1 iv for RSTP (Rapid Spanning Tree Protocol) IEEE 802.1 is for MSTP (Multiple Spanning Tree Protocol) IEEE 802.1 ix for Authentication IEEE 802.1 ix for Authentication IEEE 802.1 ix for PoE specification  |  |  |   |
| MAC Table  | 8K  |  |  |   |
| Priority Queues  | 8   |  |  |   |
| Processing   | Store-and-Forward   |  |  |   |
| Switch Properties  | Switching latency: 7 us Switching bandwidth: 40 Gbps Max. Number of Available VLANs: 256 IGMP multicast groups: 128 for each VLA Port rate limiting: User Define  |  |  |   |
| Jumbo frame  | Up to 9.6K Bytes  |  |  |   |
| Security Features  | Device Binding security feature Enable/disable ports, MAC based port security Port based network access control (802.1x) VLAN (802.1Q) to segregate and secure network traffic Radius centralized password management SNMP v1/v2c/v3 encrypted authentication and access security Https / SSH enhance network security  |  |  |   |
| Software Features  | STP/RSTP/MSTP (IEEE 802.1D/w/s) Redundant Ring (0-Ring) with recovery time less than 10ms over 250units TOS/Diffserv supported Quality of Service (802.1p) for real-time traffic VLAN (802.1c) with VLAN tagging and GVRP supported IGMP Snooping for multicast filtering Port configuration, status, statistics, monitoring, security SNTP for synchronizing of clocks over network Support PTP Client (Precision Time Protocol) clock synchronization DHCP Server / Client support POrt Trunk support MVR (Multicast VLAN Registration) support MVR (Multicast VLAN Registration) support |  |  |   |
| Network Redundancy   | O-Ring Open-Ring O-C-hain MRP STP/RSTP/MSTP   |  |  |   |
| Warning / Monitoring System  | Relay output for fault event alarming Syslog server / client to record and view events Include SMTP for event warning notification via email Event selection support  |  |  |   |
| RS-232 Serial Console Port   | RS-232 in M12 (5-pin M12 A-coding) connector with console cable. 115200bps, 8, N, 1   |  |  |   |
| Fault Contact  |   |  |  |   |
| Relay  | Relay output to carry capacity of 3A at 24VDC on M12 connector (5-pin M12 A-coding)   |  |  |   |
| Power  Redundant Input Power                                       | Dual DC inputs. 50~57VDC<br>on 5-pin M23 connector  | Dual DC inputs. 24 (12~57)<br>VDC on 5-pin M23 connector     |  | Dual DC inputs. 24 (12~57<br>VDC on 5-pin M23 connecto      |
| Power Consumption(Typ.)  | 20 Watts (power   | 25 Watts (power<br>consumption of P.S.E. is not<br>included) | 20 Watts (power consumption of P.S.E. is not included) | 25 Watts (power<br>consumption of P.S.E. is no<br>included) |

